**Relay assignment before production period 31.05.2006**

*20 to 72* *Fuses*
*K to P* *Relays*
*R to T* *Relays*

*F4* *Load compartment fuse and relay box*

The load compartment fuse and relay box is installed in the load compartment on the right of the wheelhouse.




P54.15-2729-03

**Relay assignment as of production period 01.06.2006**

*20 to 72* *Fuses*
*K to P* *Relays*
*R to V* *Relays*

*F4* *Load compartment fuse and relay box*

The load compartment fuse and relay box is installed in the load compartment on the right of the wheelhouse.




P54.15-2966-03

| Relays | Designation |
|---|---|
| K | **Before production period 31.05.2006**<br>● Terminal 15R power outlet relay, with power-down<br>**As of production period 01.06.2006**<br>● Circuit 15R seat adjustment |
| L | **Valid for code 550 Trailer hitch:**<br>Terminal 30X |
| M | Heated rear window relay |
| N | Circuit 15 relay / terminal 87FW |
| O | Fuel pump relay |
| P | Rear wiper relay |
| R | Circuit R relay115R |
| S | - |

| | |
|---|---|
| T | **As of production period 01.06.2006**<br>● Circuit 30, socket for 2nd seat row and load compartment |
| U | **As of production period 01.06.2006**<br>● Circuit 30, trailer |
| V | **As of production period 01.06.2006**<br>- |